

# SERVICE NOTICE

When troubleshooting an issue with the backup lights on some BBCV Vision units, you may find the circuit labeled "Stop Arm" actually contains the relay for the "Backup Light Circuit". See FIG #1




FIG #1

The correct relay location for the Backup Circuit Relay is shown below in FIG #2




FIG #2