

Cummins CM2150 Fuel Engine

(4021570) ISB, ISC, ISL, ISDe, and QSB3.3 CM2150 Electronic Control System Troubleshooting and Repair Manual

Search Manual

[Help With Printing](#)

SPN FIRST No.
FMI SECOND No.

- [-] front
- [+] Section i - Introduction
- [+] Section E - Engine Identification
- [+] Section F - Familiarization
- [+] Section FA - Automotive Features
- [+] Section TF - Troubleshooting Fault Codes

- (08-fc111) Electronic Control Module Critical Internal Failure - Bad Intelligent Device or Component 629 12
- (08-fc115) Engine Magnetic Speed/Position Lost Both of Two Signals - Data Erratic, Intermittent, or Incorrect 612 2
- (08-fc122) Intake Manifold 1 Pressure Sensor Circuit - Voltage Above Normal or Shorted to High Source 102 3
- (08-fc123) Intake Manifold 1 Pressure Sensor Circuit - Voltage Below Normal or Shorted to Low Source 102 4
- (08-fc124) Intake Manifold 1 Pressure - Data Valid but Above Normal Operational Range - Moderately Severe Level
- (08-fc131) Accelerator Pedal or Lever Position Sensor 1 Circuit - Voltage Above Normal or Shorted to High Source 91 3
- (08-fc132) Accelerator Pedal or Lever Position Sensor 1 Circuit - Voltage Below Normal or Shorted to Low Source 91 4
- (08-fc133) Remote Accelerator Pedal or Lever Position Sensor 1 Circuit - Voltage Above Normal or Shorted to High Source 974 3
- (08-fc134) Remote Accelerator Pedal or Lever Position Sensor 1 Circuit - Voltage Below Normal or Shorted to Low Source 974 4
- (08-fc135) Engine Oil Rifle Pressure 1 Sensor Circuit - Voltage Above Normal or Shorted to High Source 100 3
- (08-fc141) Engine Oil Rifle Pressure 1 Sensor Circuit - Voltage Below Normal or Shorted to Low Source 100 4
- (08-fc143) Engine Oil Rifle Pressure - Data Valid but Below Normal Operational Range - Moderately Severe Level 100 1
- (08-fc144) Engine Coolant Temperature 1 Sensor Circuit - Voltage Above Normal or Shorted to High Source 110 3
- (08-fc145) Engine Coolant Temperature 1 Sensor Circuit - Voltage Below Normal or Shorted to Low Source 110 4
- (08-fc146) Engine Coolant Temperature - Data Valid but Above Normal Operational Range - Moderately Severe Level 110 0
- (08-fc151) Engine Coolant Temperature - Data Valid but Above Normal Operational Range - Most Severe Level 110 0
- (08-fc153) Intake Manifold 1 Temperature Sensor Circuit - Voltage Above Normal, or Shorted to High Source 105 3
- (08-fc154) Intake Manifold 1 Temperature Sensor Circuit - Voltage Below Normal or Shorted to Low Source 105 4
- (08-fc155) Intake Manifold 1 Temperature - Data Valid but Above Normal Operational Range - Most Severe Level 105 0
- (08-fc195) Coolant Level Sensor 1 Circuit Choice 111 3
- (08-fc195-2wire) Coolant Level Sensor 1 Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc195-3wire) Coolant Level Sensor 1 Circuit - Voltage Above Normal or Shorted to High Source 111 3
- (08-fc196) Coolant Level Sensor 1 Circuit Choice 111 4
- (08-fc196-2wire) Coolant Level Sensor 1 Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc196-3wire) Coolant Level Sensor 1 Circuit - Voltage Below Normal or Shorted to Low Source 111 3
- (08-fc197) Coolant Level - Data Valid but Below Normal Operational Range - Moderately Severe Level
- (08-fc221) Barometric Pressure Sensor Circuit - Voltage Above Normal or Shorted to High Source 111 1 or 112 18
- (08-fc222) Barometric Pressure Sensor Circuit - Voltage Below Normal or Shorted to Low Source 108 4
- (08-fc234) Engine Crankshaft Speed/Position - Data Valid but Above Normal Operational Range - Most Severe Level 190 0
- (08-fc238) Sensor Supply 3 Circuit - Voltage Below Normal or Shorted to Low Source 3511 4
- (08-fc239) Sensor Supply 3 Circuit - Voltage Above Normal, or Shorted to High Source 3511 3
- (08-fc241) Wheel-Based Vehicle Speed - Data Erratic, Intermittent or Incorrect 84 2
- (08-fc242) Wheel-Based Vehicle Speed Sensor Circuit Tampering Has Been Detected - Abnormal Rate of Change 84 10
- (08-fc245) Fan Control Circuit - Voltage Below Normal or Shorted to Low Source 647 4
- (08-fc249) Ambient Air Temperature Sensor 1 Circuit - Voltage Above Normal or Shorted to High Source 171 3
- (08-fc252) Engine Oil Level - Data Erratic, Intermittent, or Incorrect 98 2
- (08-fc253) Engine Oil Level - Data Valid but Below Normal Operational Range - Most Severe Level 95 1
- (08-fc256) Ambient Air Temperature Sensor Circuit 171 4
- (08-fc271) Fuel Pump Pressurizing Assembly 1 Circuit - Voltage Below Normal or Shorted to Low Source 1347 4
- (08-fc272) Fuel Pump Pressurizing Assembly 1 Circuit - Voltage Above Normal or Shorted to High Source 1347 3
- (08-fc281) Fuel Pump Pressurizing Assembly 1 - Mechanical System Not Responding Properly or Out of Adjustment 1347 7
- (08-fc285) SAE J1939 Multiplexing PGN Timeout Error - Abnormal Update Rate 639 13
- (08-fc286) SAE J1939 Multiplexing Configuration Error - Out of Calibration 639 13
- (08-fc287) SAE J1939 Multiplexed Accelerator Pedal or Lever Sensor System - Received Network Data In Error 91 2
- (08-fc288) SAE J1939 Multiplexing Remote Accelerator Pedal or Lever Position Sensor System - Received Network Data In Error 974 2
- (08-fc292) Auxiliary Temperature Sensor Input 1 - Special Instructions 441 14
- (08-fc293) Auxiliary Temperature Sensor Input 1 Circuit - Voltage Above Normal, or Shorted to High Source 441 3
- (08-fc294) Auxiliary Temperature Sensor Input 1 Circuit - Voltage Below Normal or Shorted to Low Source 441 4
- (08-fc295) Barometric Pressure - Data Erratic, Intermittent, or Incorrect 108 2
- (08-fc296) Auxiliary Pressure Sensor Input 1 - Special Instructions 1388 14

- (08-fc297) Auxiliary Pressure Sensor Input 1 Circuit - Voltage Above Normal or Shorted to High Source 1388 3
- (08-fc298) Auxiliary Pressure Sensor Input 1 Circuit - Voltage Below Normal or Shorted to Low Source 1388 4
- (08-fc322) Injector Solenoid Driver Cylinder 1 Circuit - Current Below Normal or Open Circuit 651-5
- (08-fc323) Injector Solenoid Driver Cylinder 5 Circuit - Current Below Normal or Open Circuit 655-5
- (08-fc324) Injector Solenoid Driver Cylinder 3 Circuit - Current Below Normal or Open Circuit 653-5
- (08-fc325) Injector Solenoid Driver Cylinder 6 Circuit - Current Below Normal or Open Circuit 656-5
- (08-fc331) Injector Solenoid Driver Cylinder 2 Circuit - Current Below Normal or Open Circuit 652-5
- (08-fc332) Injector Solenoid Driver Cylinder 4 Circuit - Current Below Normal or Open Circuit 654-5
- (08-fc334) Engine Coolant Temperature - Data Erratic, Intermittent, or Incorrect 110-2
- (08-fc343) Engine Control Module Warning Internal Hardware Failure - Bad Intelligent Device or Component
- (08-fc351) Injector Power Supply - Bad Intelligent Device or Component
- (08-fc352) Sensor Voltage Supply
- (08-fc386) Sensor Supply 1 Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc415) Engine Oil Rifle Pressure - Data Valid but Below Normal Operational Range - Most Severe Level
- (08-fc418) Water in Fuel Indicator - Data Valid but Above Normal Operational Range - Least Severe Level
- (08-fc427) SAE J1939 Datalink - Abnormal Update Rate 97 0
- (08-fc428) Water-in-Fuel Indicator Sensor Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc429) Water-in-Fuel Indicator Sensor Circuit - Voltage Below Normal or Shorted to Low Source 97 3
- (08-fc431) Accelerator Pedal or Lever Idle Validation Switch - Data Erratic, Intermittent, or Incorrect SPN 97 Fmi 4
- (08-fc432) Accelerator Pedal or Lever Idle Validation Circuit - Out of Calibration
- (08-fc435) Engine Oil Rifle Pressure Choice
- (08-fc435b) Engine Oil Rifle Pressure - Data Erratic, Intermittent, or Incorrect
- (08-fc435c) Engine Oil Rifle Pressure - Data Erratic, Intermittent, or Incorrect
- (08-fc441) Battery 1 Voltage - Data Valid but Below Normal Operational Range - Moderately Severe Level
- (08-fc442) Battery 1 Voltage - Data Valid but Above Normal Operational Range - Moderately Severe Level
- (08-fc449) Injector Metering Rail 1 Pressure Choice
- (08-fc449b) Injector Metering Rail 1 Pressure - Data Valid but Above Normal Operational Range - Most Severe Level
- (08-fc449c) Injector Metering Rail 1 Pressure - Data Valid but Above Normal Operational Range - Most Severe Level
- (08-fc451) Injector Metering Rail 1 Pressure Sensor Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc452) Injector Metering Rail 1 Pressure Sensor Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc471) Engine Oil Level - Data Valid but Below Normal Operational Range - Least Severe Level
- (08-fc488) Intake Manifold 1 Temperature - Data Valid but Above Normal Operational Range - Moderately Severe Level
- (08-fc499) Engine Oil Level Sensor Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc528) Auxiliary Alternate Torque Validation Switch - Data Erratic, Intermittent, or Incorrect
- (08-fc529) Auxiliary Input/Output 3 Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc553) Injector Metering Rail 1 Pressure Choice
- (08-fc553b) Injector Metering Rail 1 Pressure - Data Valid but Above Normal Operational Range - Moderately Severe Level
- (08-fc553c) Injector Metering Rail 1 Pressure - Data Valid but Above Normal Operational Range - Moderately Severe Level
- (08-fc554) Injector Metering Rail 1 Pressure - Data Erratic, Intermittent, or Incorrect
- (08-fc555) Crankcase Pressure Choice
- (08-fc555b) Crankcase Pressure - Data Valid but Above Normal Operational Range - Moderately Severe Level
- (08-fc555c) Crankcase Pressure - Data Valid but Above Normal Operational Range - Moderately Severe Level
- (08-fc556) Crankcase Pressure Choice
- (08-fc556b) Crankcase Pressure - Data Valid but Above Normal Operational Range - Most Severe Level
- (08-fc556c) Crankcase Pressure - Data Valid but Above Normal Operational Range - Most Severe Level
- (08-fc559) Injector Metering Rail 1 Pressure Choice
- (08-fc559b) Injector Metering Rail 1 Pressure - Data Valid but Below Normal Operational Range - Moderately Severe Level 157 - 18
- (08-fc559c) Injector Metering Rail 1 Pressure - Data Valid but Below Normal Operational Range - Moderately Severe Level
- (08-fc584) Starter Relay Driver Circuit - Voltage Above Normal or Shorted to High Source 677 3
- (08-fc585) Starter Relay Driver Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc596) Electrical Charging System Voltage - Data Valid but Above Normal Operational Range - Moderately Severe Level
- (08-fc597) Electrical Charging System Voltage - Data Valid but Below Normal Operational Range - Moderately Severe Level
- (08-fc598) Electrical Charging System Voltage - Data Valid but Below Normal Operational Range - Most Severe Level
- (08-fc599) Auxiliary Commanded Dual Output Shutdown - Special Instructions
- (08-fc649) Engine Oil Change Interval - Condition Exists
- (08-fc686) Turbocharger 1 Speed - Data Erratic, Intermittent, or Incorrect SPN 103 2
- (08-fc687) Turbocharger 1 Speed - Data Valid but Below Normal Operational Range - Moderately Severe Level
- (08-fc688) Engine Oil Level - Data Valid but Above Normal Operational Range - Most Severe Level
- (08-fc689) Engine Crankshaft Speed/Position - Data Erratic, Intermittent, or Incorrect
- (08-fc691) Turbocharger 1 Compressor Inlet Temperature Sensor Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc692) Turbocharger 1 Compressor Inlet Temperature Sensor Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc698) ECM Internal Temperature Sensor Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc731) Engine Speed/Position Camshaft and Crankshaft Misalignment - Mechanical System Not Responding Properly or Out of Adjustment
- (08-fc778) Engine Camshaft Speed/Position Sensor - Data Erratic, Intermittent, or Incorrect

- (08-fc779) Auxiliary Equipment Sensor Input 3 - Root Cause Not Known
- (08-fc784) Adaptive Cruise Control Mode - Data Erratic, Intermittent, or Incorrect
- (08-fc1117) Power Supply Lost With Ignition On - Data Erratic, Intermittent, or Incorrect
- (08-fc1239) Accelerator Pedal or Lever Position Sensor 2 Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc1241) Accelerator Pedal or Lever Position Sensor 2 Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc1242) Accelerator Pedal or Lever Position Sensor 1 and 2 - Data Erratic, Intermittent, or Incorrect
- (08-fc1663) Catalyst Inlet Temperature Sensor Swapped with Outlet - Condition Exists
- (08-fc1664) Catalyst Missing - Condition Exists
- (08-fc1665) Aftertreatment Exhaust Gas Temperature 1 Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc1666) Aftertreatment Exhaust Gas Temperature 1 Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc1667) Aftertreatment Exhaust Gas Temperature 1 - Data Erratic, Intermittent, or Incorrect 3241 2
- (08-fc1674) Aftertreatment Exhaust Gas Temperature 2 Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc1675) Aftertreatment Exhaust Gas Temperature 2 Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc1676) Aftertreatment Exhaust Gas Temperature 2 - Data Erratic, Intermittent, or Incorrect
- (08-fc1691) Catalyst Efficiency - Out of Calibration
- (08-fc1695) Sensor Supply 5 - Voltage Above Normal or Shorted to High Source
- (08-fc1696) Sensor Supply 5 - Voltage Below Normal or Shorted to Low Source
- (08-fc1843) Crankcase Pressure Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc1844) Crankcase Pressure Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc1866) Exhaust Gas Recirculation Valve Delta Pressure - Data Erratic, Intermittent, or Incorrect 411 2
- (08-fc1876) Exhaust Gas Temperature 3 Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc1877) Exhaust Gas Temperature 3 Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc1878) Exhaust Gas Temperature 3 - Data Erratic, Intermittent, or Incorrect 3245 2
- (08-fc1879) Aftertreatment Particulate Filter Differential Pressure Sensor Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc1881) Aftertreatment Particulate Filter Differential Pressure Sensor Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc1883) Aftertreatment Particulate Filter Differential Pressure Sensor - Data Erratic, Intermittent, or Incorrect
- (08-fc1896) EGR Valve Controller - Out of Calibration SPN 2791 FMI 13 SID 146-13
- (08-fc1899) Exhaust Gas Recirculation Valve Delta Pressure - Data Valid but Above Normal Operational Range - Moderately Severe Level
- (08-fc1911) Injector Metering Rail 1 Pressure Choice
- (08-fc1911b) Injector Metering Rail 1 Pressure - Data Valid but Above Normal Operational Range - Most Severe Level
- (08-fc1911c) Injector Metering Rail 1 Pressure - Data Valid but Above Normal Operational Range - Most Severe Level
- (08-fc1921) Aftertreatment Particulate Filter Differential Pressure - Data Valid but Above Normal Operational Range - Moderately Severe Level
- (08-fc1922) Aftertreatment Particulate Filter Differential Pressure - Data Valid but Above Normal Operational Range - Most Severe Level
- (08-fc1938) ECU Power Output Supply Voltage 1 - Data Valid but Below Normal Operational Range - Moderately Severe Level
- (08-fc1942) Crankcase Pressure - Data Erratic, Intermittent, or Incorrect
- (08-fc1943) Ambient Air Density - Data Valid but Below Normal Operational Range - Least Severe Level
- (08-fc1962) VGT Actuator Driver Over Temperature (Calculated) - Data Valid but Above Normal Operational Range - Least Severe Level
- (08-fc1966) Aftertreatment Exhaust Gas Temperature 1 - Data Valid but Above Normal Operational Range - Most Severe Level
- (08-fc1968) Aftertreatment Exhaust Gas Temperature 2 - Data Valid but Above Normal Operational Range - Moderately Severe Level
- (08-fc1969) Aftertreatment Exhaust Gas Temperature 2 - Data Valid but Above Normal Operational Range - Most Severe Level
- (08-fc1972) Aftertreatment Exhaust Gas Temperature 3 - Data Valid but Above Normal Operational Range - Moderately Severe Level
- (08-fc1973) Aftertreatment Exhaust Gas Temperature 3 - Data Valid but Above Normal Operational Range - Most Severe Level
- (08-fc1974) Crankcase Pressure - Data Valid but Above Normal Operational Range - Least Severe Level
- (08-fc1981) Aftertreatment Particulate Filter Differential Pressure - Data Valid but Above Normal Operational Range - Least Severe Level
- (08-fc1993) Aftertreatment Particulate Filter Missing - Condition Exists
- (08-fc2182) Engine Brake Actuator Driver 1 Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc2183) Engine Brake Actuator Driver 1 Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc2185) Sensor Supply 4 Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc2186) Sensor Supply 4 Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc2195) Auxiliary Equipment Sensor Input 3 Engine Protection Critical - Special Instructions
- (08-fc2198) VGT Actuator Driver Circuit - Root Cause Not Known
- (08-fc2265) Electric Lift Pump for Engine Fuel Supply Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc2266) Electric Lift Pump for Engine Fuel Supply Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc2272) EGR Valve Position Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc2273) Exhaust Gas Recirculation Valve Delta Pressure Sensor Circuit - Voltage Above Normal or Shorted to High Source
- (08-fc2274) Exhaust Gas Recirculation Valve Delta Pressure Sensor Circuit - Voltage Below Normal or Shorted to Low Source
- (08-fc2288) Turbocharger 1 Speed - Data Valid but Above Normal Operational Range - Least Severe Level
- (08-fc2311) Electronic Fuel Injection Control Valve Circuit - Condition Exists
- (08-fc2321) Engine Crankshaft Speed/Position - Data Erratic, Intermittent, or Incorrect
- (08-fc2322) Engine Camshaft Speed/Position Sensor - Data Erratic, Intermittent, or Incorrect
- (08-fc2345) Turbocharger 1 Speed - Abnormal Rate of Change
- (08-fc2346) Turbocharger Turbine Inlet Temperature (Calculated) - Data Valid but Above Normal Operational Range - Least Severe Level
- (08-fc2347) Turbocharger Compressor Outlet Temperature (Calculated) - Data Valid but Above Normal Operational Range - Least Severe Level
- (08-fc2349) EGR Valve Control Circuit - Current Below Normal, or Open Circuit

- [\(08-fc2351\) EGR Valve Control Circuit - Voltage Below Normal or Shorted to Low Source](#)
- [\(08-fc2357\) EGR Valve Control Circuit - Mechanical System Not Responding Properly or Out of Adjustment](#)
- [\(08-fc2359\) Exhaust Gas Recirculation Valve Delta Pressure - Data Valid but Above Normal Operational Range - Moderately Severe Level](#)
- [\(08-fc2363\) Engine Brake Actuator Driver Output 2 Circuit - Voltage Below Normal or Shorted to Low Source](#)
- [\(08-fc2367\) Engine Brake Actuator Driver Output 2 Circuit - Voltage Above Normal or Shorted to High Source](#)
- [\(08-fc2373\) Exhaust Gas Pressure Sensor Circuit - Voltage Above Normal or Shorted to High Source](#)
- [\(08-fc2374\) Exhaust Gas Pressure Sensor Circuit - Voltage Below Normal or Shorted to Low Source](#)
- [\(08-fc2375\) Exhaust Gas Recirculation Temperature Sensor Circuit - Voltage Above Normal or Shorted to High Source](#)
- [\(08-fc2376\) Exhaust Gas Recirculation Temperature Sensor Circuit - Voltage Below Normal or Shorted to Low Source](#)
- [\(08-fc2377\) Fan Control Circuit — Voltage Above Normal or Shorted to High Source](#)
- [\(08-fc2387\) VGT Actuator Driver Circuit \(Motor\) - Mechanical System Not Responding Properly, or Out of Adjustment](#)
- [\(08-fc2448\) Coolant Level - Data Valid but Below Normal Operational Range - Least Severe Level](#)
- [\(08-fc2449\) VGT Actuator Controller - Out of Calibration](#)
- [\(08-fc2451\) Turbocharger Turbine Inlet Temperature \(Calculated\) - Data Valid but Above Normal Operational Range - Moderately Severe Level](#)
- [\(08-fc2554\) Exhaust Gas Pressure - Data Erratic, Intermittent, or Incorrect 1209 2](#)
- [\(08-fc2555\) Intake Air Heater 1 Circuit - Voltage Above Normal or Shorted to High Source](#)
- [\(08-fc2556\) Intake Air Heater 1 Circuit - Voltage Below Normal or Shorted to Low Source](#)
- [\(08-fc2557\) Auxiliary PWM Driver 1 Circuit - Voltage Above Normal or Shorted to High Source](#)
- [\(08-fc2558\) Auxiliary PWM Driver 1 Circuit - Voltage Below Normal or Shorted to Low Source](#)
- [\(08-fc2634\) VGT Actuator Controller - Bad Intelligent Device or Component](#)
- [\(08-fc2635\) VGT Actuator Driver Circuit - Condition Exists](#)
- [\(08-fc2636\) VGT Actuator Driver Circuit - Abnormal Update Rate 641 9](#)
- [\(08-fc2637\) Catalyst Face Plugged - Root Cause Not Known](#)
- [\(08-fc2638\) Catalyst Efficiency - Out of Calibration](#)
- [\(08-fc2639\) Aftertreatment Particulate Filter Differential Pressure - Data Valid but Above Normal Operational Range - Least Severe Level 3251 0 or 15](#)
- [\(08-fc2646\) Engine Coolant Temperature - Condition Exists](#)
- [\(08-fc2659\) Engine Coolant Temperature - Condition Exists](#)
- [\(08-fc2728\) Aftertreatment Fuel Injector 1 - Data Valid but Above Normal Operational Range - Moderately Severe Level](#)
- [\(08-fc2742\) Aftertreatment Exhaust Gas Temperature 2 - Data Valid but Below Normal Operational Range - Least Severe Level](#)
- [\(08-fc2743\) Aftertreatment Exhaust Gas Temperature 2 - Data Valid but Below Normal Operational Range - Moderately Severe Level](#)
- [\(08-fc2754\) Engine Particulate Filter Inlet Pressure - Data Valid but Above Normal Operational Range - Moderately Severe Level](#)
- [\(08-fc2765\) Engine Injector Bank 1 Barcodes - Out of Calibration](#)
- [\(08-fc2777\) Particulate Trap Active Regeneration Inhibited Due to Permit Switch - Condition Exists](#)
- [\(08-fc2778\) Aftertreatment Fuel Rate - Data Valid but Above Normal Operational Range - Moderately Severe Level](#)
- [\(08-fc2813\) EGR Valve Control - Special Instructions](#)
- [\(08-fc2961\) Exhaust Gas Recirculation Temperature - Data Valid but Above Normal Operational Range - Least Severe Level](#)
- [\(08-fc2962\) Exhaust Gas Recirculation Temperature - Data Valid but Above Normal Operational Range - Moderately Severe Level](#)
- [\(08-fc2963\) Engine Coolant Temperature — Data Valid but Above Normal Operational Range — Least Severe Level](#)
- [\(08-fc2964\) Intake Manifold 1 Temperature — Data Valid but Above Normal Operational Range — Least Severe Level](#)
- [\(08-fc2973\) Intake Manifold 1 Pressure - Data Erratic, Intermittent, or Incorrect](#)

- [+ Section TS - Troubleshooting Symptoms](#)
- [+ Section TT - Troubleshooting Symptoms \(New Format\)](#)
- [+ Section 19 - Electronic Engine Controls - Group 19](#)
- [+ Section L - Service Literature](#)
- [+ Section V - Specifications](#)
- [+ back](#)

Copyright © 2000-2009 Cummins Inc. All rights reserved