

Tech Tip

FROM YOUR FRIENDS AT
NEW YORK BUS SALES!



Microbird G5 Rear Destination Sign Bulbs

Complaint – The lights are blown for the rear destination sign – How do you change them?

Cause – While most of our applications where illuminated “School Bus” signs are used there is a “door” to access the lights – the G5 does not

Correction – Please follow the steps below to gain access to change the bulbs-



Locate the padded header
over the rear entrance door



Locate the 2 “buttons” and remove them which will access 2 phillipshead screws – shown at left




Once the screws are removed you will need to pull slightly at each corner as there are Velcro strips at each corner also – remove pad as shown at left



Once the pad is removed, bending down and looking to the inner side of the rear panel you can see the 4 light sockets



Reaching in through the 2 openings you can access the 4 sockets and change the bulbs



NEW YORK BUS SALES

*We recommend changing ALL
4 bulbs
Bulb #105*

Contact Our Service Department With Any Questions

CHITTENANGO – phone 800-962-5768 or
Daryl Wallace : dwallace@newyorkbussales.com
Brian Lamaitis : blamaitis@newyorkbussales.com

ROCHESTER – phone 800-463-3232 or
Gary Chichester: gchichester@newyorkbussales.com

ALBANY – phone 866-867-1100 or
Ben Reiling: breiling@newyorkbussales.com
Steve Searles: ssearles@newyorkbussales.com

WARRANTY – 800-962-5768 ext 237
Morgan Jenkins: mjenkins@newyorkbussales.com

ALL of our Tech Tips can be found on the New York Bus Sales website at
<http://www.newyorkbussales.com/pages/bulletins.cfm>
Or at the New York Head Mechanic website at
<http://www.nyhma.org/viewforum.php?f=2&start=0>